

RM3 STEERING DAMPER FOR: CFMOTO 450MT

We appreciate your support and hope you enjoy your ride more than ever after this installing our products!

If you have any questions regarding the fitment or function of this product please call or message us 02 43741655 or info@mscmoto.com

MSC Products Australia does recommend this installation be completed by a competent mechanically minded person with the correct tools and equipment. Incorrect installation of after market parts to motorcycles can result in a product under performing, damaging the motorcycle or be harmful to the rider. Please take care when working on your motorcycle.

WHAT IS NEEDED FOR THIS INSTALLATION:

QUALITY TOOLS:

Socket Set, Allen Key set



Tidy Work Area, Secure stand or work bench for motorcycle
Owners manual - Refer to owners manual for torque settings etc

RM3 DAMPER ADJUSTMENT DETAILS

20 clicks of adjustment on main dial;

Soft - Anti-clockwise ←

Hard - Clockwise →

It may take a few rides to work out your desired dampening depending on your style or conditions you ride in. Start your first ride with dials set in the middle, if you want more or less damping adjust the dial in the direction you need a few clicks at a time.

PLEASE NOTE:

Once dial has stopped clicking/turning, the damper has reached the end of adjustment range. Please do not attempt to turn the dial any more, doing this will damage the Damper.



RM3 STEERING DAMPER FOR: CFMOTO 450MT

HOW TO INSTALL:

Start with putting the bike on a secure stand and getting some containers to place the small screws you need to remove.

Pro Tip: We also recommend that you also take some photos to help remember where everything goes!

1.

Start with removing your handlebars and the bar mounts from the top triple clamp.



2.

Now place the damper mount bracket on to the triple clamp, place the bar mounts on top of the damper mount bracket and ensure the mounts are facing in the forward position, as seen in image. The handlebars can now be re-installed.



3.

Infront of the tank is a black plastic cap, unscrewing this cap with reveal a M8 thread in the frame.

5.

Using the M8 countersunk bolt supplied, screw the post plate part down on to the frame.

RM3 STEERING DAMPER FOR: CFMOTO 450MT

INSTALL REFERENCE IMAGES



RM3 STEERING DAMPER FOR: CFMOTO 450MT

HOW TO INSTALL:

Start with putting the bike on a secure stand and getting some containers to place the small screws you need to remove.

Pro Tip: We also recommend that you also take some photos to help remember where everything goes!

6.

Now screw the pin block on to the post plate using the screws supplied.



7.

Now sit the RM3 steering damper unit on to the mount bracket with the linkage arm located over the pin tower. Screw the damper unit to the bracket using M6x16mm screws.



8.

Replace the handlebars and top bar clamp caps (If not previously re-installed).